



- 1. As shown in Figure 1, insert the screw into the large sliding screw clamping groove.
- 2. as shown in Figure 2, insert the large sliding screw into the clamping groove at the bottom of the link bridge.
- 3. As shown in Figure 3, align the screw of the link bridge and the large sliding screw clamping groove with the hole of the toilet installation sleeve to install the seat sleeve.
- 4. As shown in Figure 4, after inserting the hole, fix the nut to the screw from the bottom to ensure the stability of the seat sleeve.

REMINDER: Please install the toilet cover first and then the toilet