
Installation Manual



Apply for following models **23002**

Please keep this page for your online registration.

FISHTBL118V1.0



WARNING



Flush all pipe work through before connecting the tap, debris in the pipe work can block the cartridge and lead to damage.







Screwdriver

Electric Drill



Adjustable Wrench






Hexagon wrench


TECHNICAL DATA


Flow Rate L/P Min							
Bar	0.2	0.5	1.0	1.5	2.0	3.0	
23002	3.6	5.8	8.3	10	11.7	14.4	

Please know and follow all applicable local plumbing codes when setting the temperature on the water heater.

Dimension Drawing








PART LIST						
1	SS RISER RAIL	5	HEADSHOWER			
2	WALL BRACKET	6	SS HOSE			
3	HOLDER	7	HANDSHOWER			
4	BODY	8	GASKET			

BEFORE INSTALLATION

- Observe all local plumbing codes.
- Make sure water supply is turned off.
- Read these instructions carefully to ensure proper installation.
- Cover your drain to avoid losing parts.
- Check to make sure you have the following parts indicated below.




Please check you have all of these items in the box.





INSTALLATION PROCEDURE

Remove the plastic backnut and washers from the water inlets.



Carefully assembly fitting on to the wall .ensuring the rubber washer or rubber cushions are in the place at the base of the fitting. Tighten the backnuts. ensuring equal torque is applied to both nuts.





AFTER INSTALLATION

Ensure that all connections are tight. Ensure that the handle is in the off position. Turn on the drain and main water supply and check for leaks. Repair as needed.

CARE & CLEANING

Your new tap is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with mild soap, rinse thoroughly with warm water and dry with a clean, soft cloth. Do not use abrasive cleaners, steel wool or harsh chemicals, as these will dull the finish. Failure to follow these instructions may void your warranty.

TROUBLE SHOOTING

If you've followed the instructions carefully and your tap still does not work properly,take these corrective steps.

Problem	Possible Cause	Solution
Insufficient water	- Aerator clogged	- Clean aerator, replace if necessary
Mixer stiff	- Cartridge defective	- Replace cartridge
Mixer dripping	- Cartridge defective	- Replace cartridge
Water leaks below handle	- Cartridge defective	- Replace cartridge
	 O-ring/rings defective 	- Replace O-ring/rings
Water leaks at the	- Loose connection	- Tighten connection
connection		